

## F760 LEG PRESS/ HACK SQUAT

Your leg muscles are the strongest and toughest muscles in your body. The BODYCRAFT F760 Linear Bearing Leg Press / Hack Squat was designed with that in mind. From the heavy gauge steel, to the industrial grade linear bearings, this machine is built to withstand the toughest workouts.

Shoulder Pads Provides the User with 12" of Travel and 13 Locking Positions for the Perfect Fit. With a Squat Range from 36" at the Lowest Point to 79" at the Highest Point, this Machine Accommodates Any Size User.



Our Lower Footplate is Gas Assisted & Features 5 Different Adjustment Angles and a Lumbar Support Pad Which Flips Up on a Hinge for Hack Squat. The Adjustments Allow the User to Correctly Position Themselves for Either Leg Press, Hack Squats, or Calf Raises.

## HIGHLIGHTS



ADJUSTABLE LOWER FOOT PLATE



ADJUSTABLE UPPER FOOT PLATE



LONG WEIGHT PLATE HOLDERS  
(UP TO NINE 1.75" INCH PLATES ON EACH SIDE)

Алматы (7273)495-231  
Ангарск (3955)60-70-56  
Архангельск (8182)63-90-72  
Астрахань (8512)99-46-04  
Барнаул (3852)73-04-60  
Белгород (4722)40-23-64  
Благовещенск (4162)22-76-07  
Брянск (4832)59-03-52  
Владивосток (423)249-28-31  
Владикавказ (8672)28-90-48  
Владимир (4922)49-43-18  
Волгоград (844)278-03-48  
Вологда (8172)26-41-59  
Воронеж (473)204-51-73  
Екатеринбург (343)384-55-89

Иваново (4932)77-34-06  
Ижевск (3412)26-03-58  
Иркутск (395)279-98-46  
Казань (843)206-01-48  
Калининград (4012)72-03-81  
Калуга (4842)92-23-67  
Кемерово (3842)65-04-62  
Киров (8332)68-02-04  
Коломна (4966)23-41-49  
Кострома (4942)77-07-48  
Краснодар (861)203-40-90  
Красноярск (391)204-63-61  
Курск (4712)77-13-04  
Курган (3522)50-90-47  
Липецк (4742)52-20-81  
Россия +7(495)268-04-70

Магнитогорск (3519)55-03-13  
Москва (495)268-04-70  
Мурманск (8152)59-64-93  
Набережные Челны (8552)20-53-41  
Нижний Новгород (831)429-08-12  
Новокузнецк (3843)20-46-81  
Ноябрьск (3496)41-32-12  
Новосибирск (383)227-86-73  
Омск (3812)21-46-40  
Орел (4862)44-53-42  
Оренбург (3532)37-68-04  
Пенза (8412)22-31-16  
Петрозаводск (8142)55-98-37  
Псков (8112)59-10-37  
Пермь (342)205-81-47  
Казахстан +7(7172)727-132

Ростов-на-Дону (863)308-18-15  
Рязань (4912)46-61-64  
Самара (846)206-03-16  
Санкт-Петербург (812)309-46-40  
Саратов (845)249-38-78  
Севастополь (8692)22-31-93  
Саранск (8342)22-96-24  
Симферополь (3652)67-13-56  
Смоленск (4812)29-41-54  
Сочи (862)225-72-31  
Ставрополь (8652)20-65-13  
Сургут (3462)77-98-35  
Сыктывкар (8212)25-95-17  
Тамбов (4752)50-40-97  
Тверь (4822)63-31-35  
Киргизия +996(312)96-26-47

Тольятти (8482)63-91-07  
Томск (3822)98-41-53  
Тула (4872)33-79-87  
Тюмень (3452)66-21-18  
Ульяновск (8422)24-23-59  
Улан-Удэ (3012)59-97-51  
Уфа (347)229-48-12  
Хабаровск (4212)92-98-04  
Чебоксары (8352)28-53-07  
Челябинск (351)202-03-61  
Череповец (8202)49-02-64  
Чита (3022)38-34-83  
Якутск (4112)23-90-97  
Ярославль (4852)69-52-93


# F760 LEG PRESS/HACK SQUAT

## FEATURES AND SPECIFICATIONS

|                         |                                                                                               |
|-------------------------|-----------------------------------------------------------------------------------------------|
| <b>SHOULDER PADS</b>    | Fully Adjustable, with 12" of Travel and 13 Positions Accommodating a Wider Range of Users.   |
| <b>SQUAT RANGE</b>      | 36" at the Lowest Point to 79" at the Highest Point                                           |
| <b>UPPER FOOT PLATE</b> | Adjust to 5 Different Angles from 75 Degrees to 135 Degrees                                   |
| <b>LOWER FOOT PLATE</b> | Adjust to 5 Different Angles                                                                  |
| <b>SQUAT PAD</b>        | Allows for Squats and Calf Raises by Pressing with Lower Lumbar, Relieving Spinal Compression |
| <b>CALF BLOCK</b>       | Removable 3" Round Calf Block. Works in Conjunction with Donkey Squat Pad or Shoulder Pads    |
| <b>BEARINGS</b>         | Industrial Grade Linear Bearings                                                              |
| <b>DESIGN</b>           | Space Saving Design: With Weight Plate Loading Under the Carriage                             |
| <b>BACK PAD</b>         | Leg Press Back Pad Features Lumbar Support and Flips Up on a Hinge for Hack Squat.            |
| <b>LEG PRESS RANGE</b>  | Leg Press Range of 23" at Lowest Point to 64" at Highest Point                                |
| <b>CONSTRUCTION</b>     | Heavy Gauge, 2" x 3" Steel Tubing and 1/4" Plate Steel.                                       |
| <b>CARRIAGE</b>         | Rides on Industrial Grade Linear Bearings, and 1.25" Case Hardened Steel Solid Guide Rods.    |
| <b>CARRIAGE WEIGHT</b>  | 75 lb. Starting Weight                                                                        |
| <b>PADS</b>             | Double Stitched Heavy Duty Upholstery and High Density Foam.                                  |
| <b>WEIGHT CAPACITY</b>  | 1,000 lbs.                                                                                    |
| <b>DIMENSIONS</b>       | 79" L x 39" W x 50" H.                                                                        |
| <b>WEIGHT</b>           | (Assembled) 373.5lb                                                                           |
| <b>FINISH</b>           | Diamond Gray and Textured Black Electrostatic Powder-Coated Finish                            |
| <b>GUIDE RODS</b>       | Rides on Industrial Grade Linear Bearings, and 1.25" Case Hardened Steel Solid Guide Rods.    |

## WARRANTY

**WARRANTY** Frame: 10 Years / Parts: 2 Years / Wear items: 6 Months



Алматы (7273)495-231  
Ангарт (3955)60-70-56  
Архангельск (8182)63-90-72  
Астрахань (8512)99-46-04  
Барнаул (3852)73-04-60  
Белгород (4722)40-23-64  
Благовещенск (4162)22-76-07  
Брянск (4832)59-03-52  
Владивосток (423)249-28-31  
Владикавказ (8672)28-90-48  
Владимир (4922)49-43-18  
Волгоград (844)278-03-48  
Вологда (8172)26-41-59  
Воронеж (473)204-51-73  
Екатеринбург (343)384-55-89

Иваново (4932)77-34-06  
Ижевск (3412)26-03-58  
Иркутск (395)279-98-46  
Казань (843)206-01-48  
Калининград (4012)72-03-81  
Калуга (4842)92-23-67  
Кемерово (3842)65-04-62  
Киров (8332)68-02-04  
Коломна (4966)23-41-49  
Кострома (4942)77-07-48  
Краснодар (861)203-40-90  
Красноярск (391)204-63-61  
Курск (4712)77-13-04  
Курган (3522)50-90-47  
Липецк (4742)52-20-81  
Россия +7(495)268-04-70

Магнитогорск (3519)55-03-13  
Москва (495)268-04-70  
Мурманск (8152)59-64-93  
Набережные Челны (8552)20-53-41  
Нижний Новгород (831)429-08-12  
Новокузнецк (3843)20-46-81  
Ноябрьск (3496)41-32-12  
Новосибирск (383)227-86-73  
Омск (3812)21-46-40  
Орел (4862)44-53-42  
Оренбург (3532)37-68-04  
Пенза (8412)22-31-16  
Петрозаводск (8142)55-98-37  
Псков (8112)59-10-37  
Пермь (342)205-81-47  
Казахстан +7(7172)727-132

Ростов-на-Дону (863)308-18-15  
Рязань (4912)46-61-64  
Самара (846)206-03-16  
Санкт-Петербург (812)309-46-40  
Саратов (845)249-38-78  
Севастополь (8692)22-31-93  
Саранск (8342)22-96-24  
Симферополь (3652)67-13-56  
Смоленск (4812)29-41-54  
Сочи (862)225-72-31  
Ставрополь (8652)20-65-13  
Сургут (3462)77-98-35  
Сыктывкар (8212)25-95-17  
Тамбов (4752)50-40-97  
Тверь (4822)63-31-35  
Киргизия +996(312)96-26-47

Тольятти (8482)63-91-07  
Томск (3822)98-41-53  
Тула (4872)33-79-87  
Тюмень (3452)66-21-18  
Ульяновск (8422)24-23-59  
Улан-Удэ (3012)59-97-51  
Уфа (347)229-48-12  
Хабаровск (4212)92-98-04  
Чебоксары (8352)28-53-07  
Челябинск (351)202-03-61  
Череповец (8202)49-02-64  
Чита (3022)38-34-83  
Якутск (4112)23-90-97  
Ярославль (4852)69-52-93

<https://bodycraft.nt-rt.ru/> || [btj@nt-rt.ru](mailto:btj@nt-rt.ru)